



Networked DVR

16CH/9CH/4CH
NW-STA-5016/5009/5004

NW-STA-5016/5009/5004 ***USER MANUAL***

Networked DVR



Product Feature

- ① 16/9/4 CH Multiple camera Input
- ② Embedded XP O/S of DOM(Disk On Memory) solution Mounted
- ③ Pentaplex Multi tasking for Monitoring And recording and searching and networking
- ④ Able to record the CIF size(320*240) video Image at the speed of 120/240/480 fps (frame for second)
- ⑤ Large quantity HDD backup function by using IEEE1394 and USB2.0 Memory and CD/DVD
- ⑥ MPEG4 H/W Compression with high compression rate 1~3K
- ⑦ Intelligent camera move away detection
- ⑧ Central Integration with CAMS Checker For Real time Health Check
- ⑨ Two Way audio communication and broadcasting by CMS,CM Server

Contents

Chapter 1	Service Requirement	3
Chapter 2	Product Information	4
Chapter 3	Basic Product Operation	6
Chapter 4	System Setup	24
Chapter 5	Firmware Upgrade	49
Chapter 6	Warranty	52

Chapter 1 **Service Requirement**

Limitation of warranty

We warrant that DVR series will be free from defects in materials and workmanship under normal use and service for all parts excluding hard drives for a period of one year after the date that the customer purchased the product.

If such a defect occurs, you should contact where you purchased and return the product to us accompanied with the proof of purchase, we will either repair or replace the product through our inspection. It is your exclusive remedy for breach of this warranty. However this warranty shall not apply on repairs or replacements necessitated by any cause as listed below.

- 1) improper installation
- 2) acts of nature
- 3) accident
- 4) lack of proper maintenance
- 5) voltage fluctuations
- 6) unauthorized repair or modifications.

For more details on the limitation of warranty, refer to entire limited warranty as appendix at the end of this manual.



Service Information

- To avoid additional defects, do not attempt to repair this unit by yourself. Please contact a local dealer/distributor/certified installer to get service from authorized technician. Unauthorized repairs will void the warrantee, may result in fire, electronic shock or other hazards.
- All shipment for repair should be prepaid and properly packed with a note outlining the defect.
- Send the product with purchase number or other related documents obtaining from Fore Tech or its agent as proof purchasing the product.

Chapter 2 Product Information

● Features

- ◆ Enable integrated video monitoring and system management by networking with maximum 1000DVRs systems through CAMS(Central Automated Monitoring System) interface.
- ◆ High quality video display and system stability through embedded operating system with hardware MPEG4 video compression chip.
- ◆ Support the max D1(720*480) quality resolution video display and 120FPS recording.
- ◆ 4/9/16 CH video input and 4 CH audio input.
- ◆ X-Triplex multitasking for video recording, playback, transmission and backup.
- ◆ Easy operation using remote-controller, full-page panel, GUI support.
- ◆ Network transmission of 30 different types of system error management information per system.
- ◆ High-speed transmitted video monitoring of ST DVRs up to 64 channels through CMS software network.
- ◆ High-speed network video monitoring by internet explorer through WEB CMS server within the system.

● System Design

- ◆ Watchdog function for hardware & software error
- ◆ Robust design for physical impact and temperature
- ◆ Generating 30 different types of network messages for system errors.
- ◆ Application of low power and low heat features for industrial environment

● General Specifications

- ◆ Advanced hardware MPEG 4
- ◆ Embedded O/S ROM
- ◆ 4/9/16 Camera input
- ◆ Auto-sequence screen division and PIP/POP function.
- ◆ Real time display
- ◆ Recording : 120fps-NTSC (PAL 100fps)
- ◆ 4 CH audio recording and two way audio communication.
- ◆ CD, DVD RW, USB external saving devices
- ◆ Ethernet 10/100Mbps, RS-232C network support
- ◆ Maximum 16 ports sensor input and 4 port alarm output
- ◆ X-plex multitasking, recording, playback, backup and network.
- ◆ STATIC, DHCP, PPPOE support


- ◆ Firmware upgrade using network and USB port.
- ◆ Remote upgrade using CMS
- ◆ Free alarm (max 30secs), port alarm (max 120secs) recording
- ◆ Watermarking
- ◆ Private backup viewer
- ◆ E-Map's layout mapping
- ◆ able to install maximum 4 HDD to save 2.5T

Chapter 3 General product operation




FRONT CASE Button Description

IV-STA-5016 (16ch)




REAR PANEL I/O Description

IV-STA-5016 (16ch)




FRONT CASE Button Description

IV-STA-5009 (9ch)




REAR PANEL I/O Description

IV-STA-5009 (9ch)




FRONT CASE Button Description

IV-STA-5004 (4ch)




REAR PANEL I/O Description

IV-STA-5004 (4ch)



Power on/off




●Power on

Press the power button at the back to be 'ON' to turn it on after connecting the power cable.

●Power off

- ① press 'Menu' button [menu → system → shutdown]
- ② select 'Shutdown' and press 'Enter' button.
- ③ select 'OK' button after the message " system will shutdown". Press 'Enter' button.
- ④ press the power switch at the back to be 'Off'.

System Login



●Input password

Input the password using number buttons at the password box.

☞ The default value is '0000'.




Screen display

[Channel status]

Channel number

Camera name

 : Recording

 : Motion detection in process

 : Sensor detection in process

 : Channel sequence indication

 : PTZ indication

[Playback status]

 : Playback in progress

 : Pause

 : Playback per frame

 : Play backward per frame

 : Speed playback

 : Double speed playback


 : Double speed play backward


 : Triple speed playback

 : Triple speed play backward

1 CAM01 R	2 CAM02 R	3 CAM03 R	4 CAM04 R
5 CAM05 R	6 CAM06 R	7 CAM07 R	8 CAM08 R
9 CAM09 R	10 CAM10 R	11 CAM11 R	12 CAM12 R
13 CAM13 R	14 CAM14 R	15 CAM15 R	16 CAM16 R
<div style="border: 1px solid red; padding: 2px;"> 2007/08/29 10:17:05 R:01 A B C D </div>			

[Slide bar]

 : CMS connection status

 : USB device connection status

Date & time

Remote controller status

[HDD status]

HDD indication

A : master hard

B : slave hard

C : master hard

D : slave hard

* color icon indications

blue : HDD installed.



yellow : recording in progress

orange : Hard disk is full



red : Hard disk error


Screen setup

● Full screen mode


-  press this button.
-  shifts to next channel each time you press this button.

● Quad screen mode


-  press this button.
-  shifts to the next channel each time you press this button.
- If you press a channel number button on remote-controller while being displayed in the current quad screen, the selected channel turns full screen.




- If you press another channel number that is not being displayed in the current quad screen, it turns another quad screen including the channel you selected.



● **9 division screen mode**


-  press this button

● **16 division screen mode**

-  press this button


● **POP screen mode *only for 9Ch & 16Ch products**

-press 'POP' button, it will display a certain channel larger than other channels.



● **OSD mode**

- press 'OSD' button, icons and channel status phrases will appear or disappear.



● PIP screen mode

You can monitor 2 screens at the same time with small screen inside of one screen.

- (1) press 'PIP' button on the remote controller.
- (2) press 'PIP' button one more time the display channels will be exchanged.




- (3) If you press a channel number button on the controller, the channel will be displayed in small screen.

Ex)



- (4) you can move the small screen using arrow buttons.




● Sequence playback screen mode

- If you press 'SEQ' button, full screen or quad screen will be displayed in sequence.
- you can setup duration time at system menu.

●SPOT screen * only for 9Ch & 16Ch products

able to display real time screen of another screen-mode in different monitor using 'SPOT OUT' port at the back of product.

▶ Press 'Function' button and select 'Spot' to set up 'SPOT' screen.



(1) type

① single channel


▶ playback only one selected channel in full screen mode.

② sequence single

▶ playback each channel in full screen mode in sequence.
▶ you can setup duration time at system menu.

③ sequence quad

▶ playback channels in quad screen mode in sequence.



No.	Camera
1	Camera 1 ~ Camera 4
2	Camera 5 ~ Camera 8
3	Camera 6 ~ Camera 9

[IV-STA-5009]

Quad No.	Camera
1	Camera 1 ~ Camera 4
2	Camera 5 ~ Camera 8
3	Camera 9 ~ Camera 12
4	Camera 13~ Camera 16

[IV-STA-5016]

▶ you can setup duration time at system menu.

Digital zoom

- press **Z/F** (ZOOM) button in full screen mode to active digital zoom.
- zoomed area moves as you press arrow buttons.
- size of zoomed area gets bigger and smaller as you press **Z/F** (ZOOM) button one more time.
- press 'Enter' button, it shows the selected area bigger like the images below.



Recording


- press 'REC' button to start recording.

Check before recording !!

- (1) Check if hard disk is formatted.
- (2) Check the camera output.
- (3) Check if each channel names are correct.
- (4) Set each channel's recording quality.
- (5) Set each channel's recording frames.

Search

- press 'SEARCH' button. Then you can see the 'Search' menu like below.




- **Search by time**

- (1) input the date and time to search. Press 'Enter' button.

- **Search by calendar**

- (1) you can see 'calendar' menu like below if you select 'Search by calendar'.
- (2) select the date and time using arrow keys. Press 'Enter' button.
- (3) lastly, select 'OK' and press 'Enter button'.



- Search by event
 - (1) you can see the menu like below if you select 'Search by event'.
 - (2) input the beginning date/time and ending date/time to search.
 - (3) select channels to search.
 - (4) select events to search.
 - (5) lastly, select search and press 'Enter' button.

The screenshot shows a 'SEARCH BY EVENT' menu with the following fields and options:

- START TIME**: [Input field]
- END TIME**: [Input field]
- CAMERA**:
 - ALL
 - CH1 CH2 CH3 CH4
 - CH5 CH6 CH7 CH8
 - CH9 CH10 CH11 CH12
 - CH13 CH14 CH15 CH16
- EVENT**:
 - MOTION
 - SENSOR
 - VLOSS
- SEARCH** button
- CLOSE** button

Callouts: 2 points to the time input fields, 3 points to the camera selection area, and 4 points to the event selection area.

- **Go to first**
playback from the beginning part of recording.
- **Go to last**
playback from the recent part of recording.

Playback

- press 'Playback' button to start playback from the recent part of recording.
- you can choose various playback screen modes by screen mode buttons.

◀◀	Rewind Frame playback	- Rewind during playback. - Playback by frame during pause.
▶	Playback	Playback the recorded screen.
	Pause	Pause the screen.
▶▶	Fast forward Frame playback	-Fast forward during playback. -Playback by frame during pause.
■	stop	Stop the playback.

Backup

- backup data using USB device.

(1) Connect 'USB' device to the DVR's USB port.



(2) Press 'Function' button and select 'Backup'

(3) Select options from menu.

BACKUP

DEVICE

MEDIA TYPE

CHANNEL

<input type="checkbox"/> ALL	<input type="checkbox"/> CH1	<input type="checkbox"/> CH2	<input type="checkbox"/> CH3	<input type="checkbox"/> CH4
<input type="checkbox"/> CH5	<input type="checkbox"/> CH6	<input type="checkbox"/> CH7	<input type="checkbox"/> CH8	<input type="checkbox"/> CH9
<input type="checkbox"/> CH10	<input type="checkbox"/> CH11	<input type="checkbox"/> CH12	<input type="checkbox"/> CH13	<input type="checkbox"/> CH14
<input type="checkbox"/> CH15	<input type="checkbox"/> CH16			


FROM

TO

- ✓DEVICE – select the device to backup.
- ✓MEDIA TYPE– select media 'CD','DVD' etc to backup.
- ✓FORMAT – format the media before backup.
- ✓CHANNEL – select channels to backup.
- ✓FROM – input the date/time to start backup.
- ✓TO – input the date/time to finish backup.

(4) Select 'BACKUP' and press 'Enter' button.

- Backup viewer



(1) open file : Load the backup data.

(2) save : save the playback images as bmp file.

(3) playback : playback the backup data. (playback, pause, speed playback, playback by frame)

(4) division : 1 division, 4 division, 9 division, 16 division

(5) watermark : check if there is any modification of data.


(6) status box : display the status of backup viewer.

- Open file



(1) Click 'Open file' button from the main screen.

(2) Select files to playback.




(3) After loading backup file is completed, you can playback backup data and save it as bmp files.

● Audio playback



- (1) Load files with audio data.
- (2) Select and playback the channel, which audio is saved, it playbacks audio data at the same time.


● Save



- (1) Save backup data.
- (2) Select screen division.
- (3) Click 'save' button.
- (4) Name the 'Bmp' file and save.

Image of saved bmp file as 9 division screen

● Watermark



- (1) Load files to check watermarking
- (2) Click 'watermark check' button.
- (3) Click playback or speed playback button.




[Watermarking Check Mode] Check Watermarking of [2006-07-24 17:00:02]

- (4) It shows the image with error message if there is any modification of data. It shows 'Ok' in the status box if there is no modification of data.

PTZ


●PTZ operation

press  button to display in full screen and you can operate PTZ cameras.

press 'Enter' button in PTZ mode, you will see 'PTZ-ADVANC' menu.

●PTZ general movement

- (1) moves pan/tilt camera from up/ down and right/ left using arrow keys.
- (2) enlarge or reduce the screen size by ◀◀ / ▶▶ buttons while using zoom camera.
- (3) can move to other channels by number button on remote controller.



●PTZ ADVANCE

(1) adjust focus

- ① + : Focus in
- ② - : Focus out
- ③ AUTO : Auto focus mode

(2) Iris control


- ① + : Open iris
- ② - : Close iris
- ③ AUTO : Auto iris mode

(3) operating speed

- ① + : increase the speed.
- ② - : decrease the speed.

(4) preset

- ① scanning
- ② shortcut



NOTE: you can set 'Preset' at System menu.
[Menu camera setup preset]

you can set 'Scan list' at System menu.
[Menu camera setup scan point]

Audio

- Turn on/ off audio.
- you can playback the audio in full screen mode.



Audio On : Turn on audio
Mute : Turn off audio

Log search

- search every event happened during product operation.

LOG VIEW

EVENT TYPE ALL

SYSTEM HDD

RECORD DB

PROCESS NETWORK

FROM

TO

- ✓ event type – select types of event to search
- ✓ from – input date/time to start searching
- ✓ to – input date/time to finish searching

- select 'Search' and press 'Enter' button to start log search.

Remote –controller ID


● Remote-controller ID

- (1) can use to operate several DVRs at one site with one remote-controller.
- (2) can operate a certain DVR according to the registered ID value.



① DVR ID

- It will turn yellow if remote controller's ID matches with DVR ID. Then you can operate the DVR.
- It will turn red if remote controller's ID does not match with DVR ID. Then you cannot operate the DVR.
- you can set the DVR IDs at System menu.
[menu system miscellaneous]
- setting up remote-controller ID
 - (1) press 'DVR-ID' button on the remote-controller.
 - (2) it will beep. Then you can input 'Remote-controller ID'.
 - (3) press the DVR ID to operate using number buttons.



Chapter 4 System setup




Before setting up system

● Starting system menu

- (1) press 'Menu' button.
- (2) input administrator's password on the password box.


NOTE: default value: 0000

● Menu format




● How to use Menu

- ✓ you can move menu cursor using arrow buttons.
- ✓ press 'Enter' button to activate the selected menu or to go to sub menu.
- ✓ press 'Menu' button to close system setup or go to the previous menu.




● **Saving/Canceling menu setup**

- saving menu setup : select 'OK' and press 'Enter' button.
- canceling menu setup : select 'Cancel' and press 'Enter' or 'Menu' buttons.



● **Text input box**


- (1) select letters/symbols using arrow buttons.
- (2) press 'Enter' button to select the letter/symbol.
- (3) the selected letters/symbols will show on the top text box.





TEXT input box

● **Moving to the next menu page**


Ex)



Press  or  button to move to the next menu page.


Setting up screen display

● Screen display setup – On Screen Display



- ✓ Status bar – indicate the status bar on the bottom of screen.
- ✓ Camera title – indicate the name of each channel.
- ✓ Camera boarder – indicate the boarder-line of each channel.
- ✓ Language – select menu language.


- ✓ Left margin – adjust the left margin of OSD.
- ✓ Right margin – adjust the right margin of OSD.
- ✓ Top margin – adjust the top margin of OSD.
- ✓ Bottom margin - adjust the bottom margin of OSD.



●Screen display setup – live sequence scanning (full screen)

Setup duration time for live sequence scanning in full screen.


NOTE : can input maximum 99 second.



●Screen display setup – live sequence scanning (quad screen)

Setup duration time for live sequence scanning in quad screen.

NOTE : can input maximum 99 second.



Quad screen number	camera
1	Camera 1 ~ Camera 4
2	Camera 5 ~ Camera 8
3	Camera 6 ~ Camera 9

[IV-STA-5009]


Quad screen number	camera
1	Camera 1 ~ Camera 4
2	Camera 5 ~ Camera 8
3	Camera 9 ~ Camera 12
4	Camera 13~ Camera 16

[IV-STA-5016]

●Screen display setup – spot sequence scanning (full screen)

Setup duration time for spot sequence scanning in full screen.


NOTE : can input maximum 99 second.



● **Screen display setup – spot sequence scanning (quad screen)**

Setup duration time for spot sequence scanning in quad screen.

NOTE : can input maximum 99 second.




Quad screen number	camera
1	Camera 1 ~ Camera 4
2	Camera 5 ~ Camera 8
3	Camera 6 ~ Camera 9

[IV-STA-5009]

Quad screen number	camera
1	Camera 1 ~ Camera 4
2	Camera 5 ~ Camera 8
3	Camera 9 ~ Camera 12
4	Camera 13~ Camera 16

[IV-STA-5016]

● **Screen display setup – miscellaneous**




● **Deinterlace**

prevent screen twittering during playback of image which is recorded in low frame rate and 720X480 or 720X576 resolution.

● **Event popup**

if any motion/ sensor activity is detected, detected channel will show in full screen.




●VGA frequency

setup the frequency of connected VGA monitor.

●Auto setup

AUTO DETECT : automatically detects video signals.

NOTE : it operates during system booting. It is booted as PAL or NTSC type according to the video signal of channel 1.



- ✓SWITCH : detect video signals according to main-board jumper within the product.
- ✓NTSC : set video signal as NTSC.
- ✓PAL : set video signal as PAL.

Camera Setup

● Camera setup – general

- title – input channel names.
- show– show or hide channels.
- audio – select connected audio channels.

CH	TITLE	SHOW	AUDIO
1	CAM01	ON	CH-01
2	CAM02	ON	CH-02
3	CAM03	ON	CH-03
4	CAM04	ON	CH-04
5	CAM05	OFF	<NONE>
6	CAM06	ON	<NONE>
7	CAM07	ON	<NONE>
8	CAM08	OFF	<NONE>

1-8 9-16 OK CANCEL

● Camera setup – PTZ


- ID – input camera IDs.
- protocol – select the registered protocol.
- baud – select the registered baud.

CH	ID	PROTOCOL	BAUD
1	000	PELCO D	4800
2	000	PELCO D	4800
3	000	PELCO D	4800
4	000	PELCO D	4800
5	000	PELCO D	4800
6	000	PELCO D	4800
7	000	PELCO D	4800
8	000	PELCO D	4800


1-8 9-16 OK CANCEL

● Camera setup – preset

NOTE : system will record according to preset positions of camera.
 check if camera supports preset function before setting up.
 can setup 64 preset positions for each channel.



- ✓ camera – select cameras to setup preset positions.
 - ✓ page – move to the next page.
 - ✓ clear all – clear all the setup values.
- (1) Select camera.
 - (2) Select 'Set' button.
 - (3) Then the channel turns PTZ mode.
 - (4) Move the camera to get the position you want.
 - (5) Press 'Enter' button to save the preset.




●Screen display setup – scan point

NOTE : you can move camera to follow the path by saved preset positions for each channel. You can set 4 scan point list for each channel.

- camera – select a camera to set scan point.
- list – select a list to save scan point.

NOTE : you can setup total 4 lists.
one scan list is consist of total 16 preset position.


- preset – select preset position you want.
- clear all – clear all setup values.




Ex)
Camera 1 will move following the path as below.
PTZ01 → 3sec→ PTZ09 → 3sec→ PTZ04 → 3sec→ PTZ25 → 3sec→ PTZ01 →.....

●Camera setup – adjusting color

- camera – select a camera.
- bright – adjust color brightness.
- contrast – adjust color contrast.
- color – adjust camera color
- default value – set it as default value.

**●Camera setup – adjusting position**

- camera – select a camera
- right/left – move the camera to right and left.
- default value – set it as default value.



Record setup

●Record setup – recording quality

CH	RESOLUTION	QUALITY	FRAMERATE
1	360X240	NORMAL	8
2	360X240	NORMAL	8
3	360X240	NORMAL	8
4	360X240	NORMAL	8
5	360X240	NORMAL	8
6	360X240	NORMAL	8
7	360X240	NORMAL	8
8	360X240	NORMAL	8
ALL	360X240	NORMAL	8

1-8 9-16 TOTAL: 120/120 OK CANCEL

➤ resolution – set recording resolution for each channel.

NTSC	PAL
720 x 480	720 x 576
720 x 240	720 x 288
352 x 240	352 x 288

➤ quality – set recording quality for each channel.

Recording quality	Display quality	HDD capacity needed
Basic	Low	Small
Normal	Normal	Medium
High	Good	Large
best	Very good	Very large

➤ Frame rate


set frame rate for each channel.

●Record setup – schedule

- system records according to set schedule.
- see below to see how to set up schedule.

C	Continuous recording
E	Recording when even occurred
(Blank)	Not recording

- (1) Select a channel to set up schedule.
- (2) Select day/time to record and press 'Enter' button.
- (3) it shifts to different type as you press 'Enter' button.


RECORD - SCHEDULE

ALL	0			5			10			15			20		
SU	C	C	C	C	C										
MO															
TU															
WE									E	E	E	E			
TH															
FR															
SA															

C: Continuous E: Event

CHANNEL

ALL


+

OK

CANCEL

● Record setup – miscellaneous

- overwrite – erase previous video data and record over it when HDD is full.
- auto delete – automatically delete data after set date.
- continuous record – you cannot stop recording while it is in process as it continuously records.
- watermark – activate watermarking function.



Event setup


NOTE : you have to set it as 'Even recording' at 'Schedule record setup' to use this function.

●Motion

CH	MOTION-AREA	SENSITIVITY	ALARM-OUT
1	ALL	5	NONE
2	ALL	5	NONE
3	OFF	0	NONE
4	OFF	0	NONE
5	ALL	5	NONE
6	ALL	5	NONE
7	ALL	5	NONE
8	ALL	5	NONE

Buttons: 1-8, 9-16, OK, CANCEL

- Motion area – select area to detect motion.
 - (1) all – set the whole screen as motion area.
 - (2) part – set motion area by block unit.



- (3) off – do not detect motion.

- sensitivity – select level of motion sensitivity.
level of sensitivity : 0 < 1 < 2 < <9

- Alarm out – set to activate alarm system when any motion is detected.

●Event setup - sensor

- record – selected channel will be recorded when the sensor is detected.
- type – set the type of connected sensor.
- alarm out – alarm is activated when the sensor is detected.

SENSOR	RECORD	TYPE	ALARM-OUT
1	OFF +	NO +	NONE +
2	OFF +	NO +	NONE +
3	OFF +	NO +	NONE +
4	OFF +	NO +	NONE +
5	OFF +	NO +	NONE +
6	OFF +	NO +	NONE +
7	OFF +	NO +	NONE +
8	OFF +	NO +	NONE +

1-8 9-16 OK CANCEL

●Event setup – alarm out

- pre-recording time – set recording time before event occurs.
- post-recording time – set recording time after event occurs.
- buzzer out – activate buzzer when the event occurs.
- alarm out time – set duration time to operate alarm system.

PRE-REC TIME 04 SEC (0-30)

POST-REC TIME 04 SEC (0-120)

BUZZER ON +

OUT TIME 005 SEC (0-120)


OK CANCEL

Storage

●Storage – format

➤ You must format HDD when you install HDD.

- (1) select installed HDD and format.
- (2) system will reboot after formatting is completed.



●Storage – AUTO-BACKUP

➤ AUTO-BACKUP –idview.com provides external USB TYPE storage. You can backup data using.


TYPE : set operation types of AUTO-BACKUP.

- (1) OFF: turn off AUTO-BACKUP function.
- (2) EXTEND: when local hard is full, it will copy old data to USB hard to extend data save time.
- (3) MIRROR: saves the same data saved in local hard to USB hard at the same time.

USB1~4 : select HDD of connected USB type.

FORMAT: format HDD of connected USB type.


SHOW: show saved file info of HDD of connected USB type.



Network

● Network – setup

- static – input static IP address and gateway, net mask.



NETWORK - SETUP

TYPE: STATIC

IP ADDRESS: 192.168.000.138

GATEWAY: 192.168.000.001

NET MASK: 255.255.255.000


MAC ADDRESS: 00:0E:00:00:00:00

PPPOR ID: [empty]

PASSWORD: ****

OK CANCEL

- DHCP – system automatically recognizes IP address.



NETWORK - SETUP

TYPE: DHCP

IP ADDRESS: 192.168.000.138

GATEWAY: 192.168.000.001

NET MASK: 255.255.255.000


MAC ADDRESS: 00:0E:00:00:00:00

PPPOR ID: [empty]

PASSWORD: ****

OK CANCEL

- PPPOE – ADSL only, input registered ID and password.



NETWORK - SETUP

TYPE: ADSL(PPPOE)

IP ADDRESS: 192.168.000.138

GATEWAY: 192.168.000.001

NET MASK: 255.255.255.000

MAC ADDRESS: 00:0E:00:00:00:00

PPPOR ID: [empty]

PASSWORD: ****

OK CANCEL

●Network - DDNS

NOTE : system supports free DDNS sites such as dyndns.com, ipupdater.com.

- server – select registered server.
- server-URL – indicate registered server URL
- user ID – input ID registered to server.
- password – input password registered to server.
- group ID – input group ID registered to server.
- status – indicate operation status of DDNS.
- test – try to connect with ID and password registered to server.

The screenshot shows a dialog box titled "NETWORK - DDNS" with a computer icon. It contains the following fields and controls:

- SERVER:** A dropdown menu with "DYNDNS.ORG" selected and a "+" button to the right.
- SERVER-URL:** A text input field containing "www.dyndns.org".
- USER ID:** An empty text input field.
- PASSWORD:** An empty text input field.
- GROUP ID:** An empty text input field.
- STATUS:** A label "DDNS OFF".
- Buttons:** "TEST", "OK", and "CANCEL" buttons at the bottom.

●Client

- password - input password to connect to CMS S/W
(same as CMS Administrator's password.)
- client port – select port to connect.
- web port – select web port to connect to web browser.
- bandwidth - limit transmitting data capacity through the network.
- DVR-ID - input DVR name to connect CMS S/W.

The screenshot shows a dialog box titled "NETWORK - CLIENT" with a computer icon. It contains the following fields and controls:

- PASSWORD:** A text input field containing "****".
- CLIENT PORT:** A dropdown menu with "7620 - 7624" selected and a "+" button to the right.
- WEB-PORT:** A text input field containing "0080".
- BANDWIDTH:** A dropdown menu with "UNLIMITED" selected and a "+" button to the right.
- DVR-ID:** A text input field containing "135".
- Buttons:** "OK" and "CANCEL" buttons at the bottom.

● Access list

- System can limit remote-PC, accessing network.
- Able to register Static IP and only remote-PC with registered IP can access system.

The screenshot shows a dialog box titled "NETWORK - ACCESS LIST" with a network icon. It contains ten input fields for IP addresses, labeled Client 1 through Client 10. Each field contains the placeholder text "000.000.000.000". At the bottom right, there are "OK" and "CANCEL" buttons.

NOTE : the system restricts all the other IPs, those are not registered if you once register an IP. If you want to access with all IP addresses, do not register any IP.

● User


- you can add user's ID and password for network connection.

The screenshot shows a dialog box titled "NETWORK - ACCESS LIST" with a network icon. It contains four rows of input fields for user information, labeled NET-ID 1 through NET-ID 4. Each row has a "USER-ID" field and a "PASSWORD" field. The password fields contain the placeholder text "****". At the bottom right, there are "OK" and "CANCEL" buttons.

- **Server**

- CC IP – input connection info of CAMS CC.
- PORT – input connection port of CAMS CC. (default value: 6500)

- CMM IP – input connection info of CAMS CMM.
- PORT – input connection port of CAMS CMM. (default value:7600)



The screenshot shows a dialog box titled "NETWORK - SERVER" with a network icon. It contains four input fields for configuration:

Field	Value
CC IP	192.168.000.131
PORT	6500
CMM IP	192.168.000.131
PORT	7600


At the bottom right, there are two buttons: "OK" and "CANCEL".

System


●System – Configuration info

NOTE : you can save the set values for menu to USB storage.

➤Load configuration – loads saved configuration information.




➤Save configuration – save the values set in the current menu.



➤Default value – set it as default value.

●System – Time management



- Current time – indicates current time of system.
- Date format – select date format to display.

classification	display
YY/MM/DD	2008/03/03
MM/DD/YY	03/03/2008
DD/MM/YY	03/03/2008

- Time format – select time format to display.

classification	display
AM/PM	01:39:01 PM
24 HOURS	13:39:01

- Time zone – select the time different from standard time of time-server.

➤ Summer time

set summer time period.

- (1) starting time : input starting date/time of summer time.
- (2) ending time : input ending date/time of summer time.

➤ Time synchronization

System automatically connects to internet time-server to check current time.

➤ Server IP – input time-server IP address.

Omit 'www'.

Select 'OK' and check if time-server works.

example) time.kriss.re.kr correct input

www.time.kriss.re.kr wrong input

➤ Change time – change system time.

NOTE : be cautious when you change system time. Because if you set the system time earlier than the time originally set, the saved data after changed system time will be deleted.

● System – Password management

SYSTEM - PASSWORD

ADIN PASSWORD

USER PASSWORD

SETUP CHECK ON

LOGIN CHECK OFF

RECORD CHECK OFF


SEARCH CHECK OFF

BACKUP CHECK OFF


- ✓ administrator password – change administrator password.
- ✓ user password – change user password.
- ✓ setup check – set whether to input user password or not before accessing system menu.
- ✓ login check – set whether to input user password or not after system booting.
- ✓ record check – set whether to input user password or not when it starts/ends recording.
- ✓ search check – set whether to input user password or not when searching record.
- ✓ backup check – set whether to input user password or not when backup.

●System – Software

- Show current software version.
- Upgrade firmware software.



●System – Miscellaneous



- ✓ Remote-controller ID – input remote controller ID.
- ✓ KEYBOARD – control the system using keyboard controller.
- ✓ Key-tone – set buzzer sound on/off for pressing button.
- ✓ Audio – set audio output on/off.

●System – System shutdown

- Select "System shutdown". If you see the message "system will shutdown", you can shutdown system.

Chapter 5 Firmware Upgrade



NOTE : There are two ways to upgrade firmware.


- (1) USB upgrade – upgrade system using USB memory stick.
- (2) NETWORK upgrade – upgrade system by internet connection.

USB upgrade

- (1) Copy the provided firmware file to USB memory stick.

NOTE : firmware file should be saved in root directory.

- (2) Connect USB memory stick to system USB port.
- (3) Press 'Menu' button and move to the next software.
[menu → system → software]
- (4) You will see a new box if you select 'Upgrade'
- (5) You will see menu like below if you select 'USB upgrade'.



- (6) Device – select USB device with firmware file.
- (7) File list – select the right firmware file.
- (8) Select 'OK'. System automatically upgrades. System will reboot after upgrade is completed.

Network upgrade


● Network upgrade

(1) Press 'Menu' button and move to the next software.

[Menu → system → software]

(2) You will see a new box if you select 'Upgrade'.

(3) Select 'Network upgrade'.



NETWORK UPGRADE

SERVER IP +

FILE NAME +

OK CANCEL

(4) Select 'Server IP' with firmware file and file name. then select 'OK'.

(5) You can manually input server IP and file name if the system appointed server IP and file name is different.

(6) System will automatically reboot after upgrade is completed.

Chapter 6 Warranty

WARRANTY

We warrant that DVR series(Product) will be free from defects in materials and workmanship for a period of one year from the date the customer acquires the Product. If such a defect occurs, return the Product to us and we will, at our opinion, either repair or replace Product. This remedy is your exclusive remedy for breach of this warranty. The proof of purchase is required for the warranty. This warranty shall not apply to repairs or replacements necessitated by any cause beyond the control of idview.com, including, but not limited to,

- 1) improper installation
- 2) acts of nature
- 3) Accident
- 4) misuse,
- 5) lack of proper maintenance
- 6) voltage fluctuations
- 7) unauthorized repairs or modifications.

This warranty gives the customer certain legal rights. Other rights, which vary from state to state or province to province, may be available to the customer.

LIMITATION OF WARRANTIES AND LIABILITY :

Except for the expressed warranty above, the Product is provided on an as is basis without an other warranties or conditions express or implied, including but not limited to warranties of

- 1) Merchantable quality
- 2) Merchant ability or fitness for a particular purpose
- 3) Those arising by law, statute, usage of trade or course of dealing.

The entire risk as to the results and performances of the Product is assumed by you. Neither we nor our dealers or suppliers shall have any liability to you or any other person or entity for any indirect, incidental, special or consequential damages whatsoever, including but not limited to, loss of revenue or profit, or other commercial or economic loss, even if we have been advised of the possibility of such damages or they are foreseeable: or for claims by a third party. Our maximum aggregate liability to you, and that of our dealers and suppliers, shall not exceed the amount paid by you for the product. The limitations in this section shall apply whether or not the alleged breach or default is a breach of a fundamental condition or term, or a fundamental breach. Some states/countries do not allow the exclusion or limitation of liability for consequential or incidental damages so the above limitation may not apply to you.

Standalone DVR/GUI
USER MANUAL