



Product: CY Series DVR


Quick Guide

A) Search and Playback Video




Playback

- 1) Press "Playback" button to go to playback window.



- 2) Select the month and date in the Calendar.
- 3) Click on the down arrow key to select the time in Hour Menu
- 4) At the bottom, you can drag the to the minute you want and then press Play button to playback video.



B) Download (Backup) Video to CD or USB Thumb Drive



Snapshot/Export/Save log


- 1) Select Snapshot to snapshot still pictures to USB thumb drive.
- 2) Select Export to backup video to USB thumb drive of CD Drive.
- 3) In the Export screen, the right column shows all the cameras.
- 4) Select the camera that you want to backup the video, and click on the plus sign.
- 5) You will see a list of dates appear under the camera.
- 6) Select the date you want to backup, and click on the plus sign.
- 7) You will see a list of times appear under the date.
- 8) Select the time and lighted it.
- 9) Press the right arrow key to move the video clip to the right column.
- 10) When you have all the video clips in the right column and ready to backup the video, Press the Burn button to begin backup.

Right arrow key to move to the right column

Rescan Device

Backup Device
CD-R, CD-RW,
USB thumb drive

Select the video clip you want to backup



Press Burn Disc to backup the video clips

Technical Support: 972-247-1203 *2